





单位:mm

出线



行程	50	100	150
L1	136	186	236
L2	124	174	224
L3	/	100	150
L4	/	80	120
N1	4	6	8
N2	1	2	3
N3	1	2	2



安装说明

- 1、主体固定时，请使用同一安装面上的所有螺丝孔固定；
- 2、拧紧螺栓时，不得超过螺纹孔深度。

